CAST ALUMINUM CRANE

MODEL 61482/61483

Care and Use

With simple, regular maintenance and care, your cast aluminum Crane will provide years of enjoyment. Occasional cleaning with mild soap and water, followed by rinsing and a thorough drying with a towel is typically all that is required. Do not use any abrasive materials, cleansers or bleach products as these may damage the finish. You should avoid allowing dirt to build up on the Crane, as this may cause it to become more difficult to remove over time.

If you notice calcium build-up on your cast aluminum Crane, you can try using a solution of 1 part white distilled vinegar and 9 parts water to help remove it. Before you apply your solution, you should always test the solution on an inconspicuous area of the Crane to ensure it doesn't discolor the finish.

For the textured surface on your Crane, it is best to periodically apply mineral oil or baby oil to prevent dirt build-up and restore the luster.

Preventative Maintenance

Periodically, you should inspect your cast aluminum Crane for any scratches or chips in the finish. For small areas, you may find the use of touch-up paint that may be purchased at a home improvement store to be the best way to restore your Crane to like-new condition.

To keep your cast aluminum Crane looking its best, you may wish to store it indoors or cover it when it is not in use for an extended period of time.

Securing Your Crane to the Ground

Your cast aluminum Crane comes with two (2) ground stakes that can be used to secure your Crane to the ground. To use the stakes, place the Crane in the area where you wish to display it and insert the stakes through the holes located in the base of the Crane. Then tap the stakes into the ground using a rubber hammer/mallet.